

Conjugated polymer nanoparticles for theranostic applications

Aliaksandra (Sasha) Rakovich
ANM, Aveiro, Portugal 2024

Slides available here:


Introduction:

- Theranostics
- Theranostic probes
- Nanomaterials for theranostics

NIR-active theranostic probes:


- CPN fabrication
- Physico-chemical properties
- Efficiency as a PDT agent
- Specificity

Conclusions & future outlook



Motivation

Theranostics aims to combine the diagnosis and therapy processes through the use of multi-modal probes



Patient outcome strongly depends on the time expired between first symptoms and the start of the treatment

Cancer Research UK. Cancer survival statistics.
<https://www.cancerresearchuk.org/health-professional/cancer-statistics/survival>, 2011.

Introduction

Theranostics
PL + PDT
CPN probes

Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy
Bioimaging

Conclusions


Theranostics = diagnosis + therapy

Theranostic probes:

- ✓ Diagnostic modality
+
e.g. MRI, fluorescence, staining, acoustic, PET
- ✓ Therapeutic modality
e.g. chemotherapy, photodynamic therapy, thermal ablation

Other (ideal) probe properties:

- ✓ Long shelf-life
- ✓ Soluble in biological fluids
- ✓ Therapeutic modality activatable
- ✓ Chemically modifiable
- ✓ Size appropriate for body clearance
- ✓ Inherently not cytotoxic



Introduction

Theranostics

PL + PDT
CPN probes

Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy
Bioimaging

Conclusions

Optical excitation-based theranostic probes


Low-cost sources available ✓

Real-time imaging ✓

Compatible with endoscopy ✓



Image from
<https://mackinawsurgerycenter.com/colon-rectal/what-is-an-endoscopy-and-why-would-my-doctor-order-one/>



- ✗ Absorption by tissues
- ✗ Relies on visual interpretation
- ✗ Few phototherapy options

Introduction

Theranostics

PL + PDT

CPN probes

Results

Fabrication

Size of CPNs

ABS and PL

PDT efficacy



Bioimaging

Conclusions

Graph from: ECE532
Biomedical Optics, © 1998
Steven L. Jacques, Scott A.
Prahl, Oregon Graduate
Institute

Photodynamic therapy

Relies on photo-initiated sensitization



PDT agents in use today:

- Organic molecules
- Short shelf-life
- Shallow penetration depth
- Poor selectivity

Introduction

Theranostics

PL + PDT

CPN probes

Results

Fabrication

Size of CPNs

ABS and PL


PDT efficacy

Bioimaging

Conclusions

Nanomaterials as theranostic probes

- Some are fluorescent
- High extinctions
- Can be made stable/soluble in water
- Appropriate size
- Further surface modification often possible



Introduction

Theranostics

PL + PDT

CPN probes

Results

Fabrication

Size of CPNs

ABS and PL


PDT efficacy

Bioimaging

Conclusions

	CLASS	SUB-CLASS	EXAMPLE / DESCRIPTION
	Molecules/ polymers	Organic fluorophores Fluorescent proteins Polymeric materials Fluorescent beads	Indocyanine green, Cy7 mNeptune, TagRFP657 Polyfluorene, poly(p-phenylenevinylene) Dye doped polymer, lipid or silica NPs
	Semi- conductor	Core type QDs Core/shell QDs Alloyed or doped QDs Silicon QDs	PbS, CdTe CdSe (core) / ZnS (shell) CuInxSe _y , Cu doped InP Si nanoparticles
	Carbon materials	Nanodiamonds Carbon dots Graphene related	NV and Si color center in diamond Graphite particle with high O and N content Graphene oxide, SWCNTs
	Metal clusters	Gold clusters Silver clusters Copper clusters	Few tens of metal atoms, stabilized in solution by ligands
	Rare-earth NPs	Upconverting NPs Downconverting NPs	Er ³⁺ or Yb ³⁺ doped NaYF ₄ Ho ³⁺ doped NaYF ₄


Conjugated Polymer Nanoparticles



Fabrication of CPN-based probes

Probe constituents

Conjugated Polymer (hydrophobic)




PTB7

known singlet oxygen producer


+

Copolymer (amphiphilic)




or

F127



Nanoprecipitation method



Introduction

Theranostics
PL + PDT
CPN probes


Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy
Bioimaging

Conclusions


Size of CPN-based probes

Dynamic Light Scattering




DLS size within the target window for body clearance

SEM



AFM



Introduction

Theranostics
PL + PDT
CPN probes



Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy
Bioimaging



Conclusions

Optical properties vs bioimaging requirements



Avoiding tissue absorption



Resistance to photobleaching



Long-term photostability



Introduction

Theranostics
PL + PDT
CPN probes

Results

Fabrication
Size of CPNs
ABS and PL

PDT efficacy
Bioimaging

Conclusions

Measurements of photodynamic efficacy *ex vitro*

Types of Reactive Oxygen Species


Test for using an
electrochemical
detection method

$^1\text{O}_2$
 $\text{HO}\cdot$
 $\cdot\text{O}_2^-$
 ONOO^-
 $\text{ROO}\cdot$
 NO
 HOCl
 H_2O_2

Singlet oxygen
Hydroxyl radical
Superoxide anion
Peroxynitrite anion
Peroxyl radical
Nitric oxide
Hypochlorous acid
Hydrogen peroxide

Test for using a relative
spectroscopic method

❖ $^1\text{O}_2$ is the major cytotoxic agent
in photodynamic therapy.



Introduction

Theranostics
PL + PDT
CPN probes

Results


Fabrication
Size of CPNs
ABS and PL
PDT efficacy

Bioimaging



Conclusions

ROS production by PTB7 CPNs *ex vitro*

Singlet oxygen





Superoxide radical



SOG production Quantum Yield

Ethanol	Water
52%	50%
8.5%	32.4%
0%	0.38%



Introduction

Theranostics
PL + PDT
CPN probes

Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy



Conclusions

Bioimaging

In vitro assays with PTB7@F127 CPNs on cancerous cells



In the dark

Intracellular ROS







Under NIR illumination

Intracellular ROS



Dose & oxidative controls



Introduction

Theranostics
PL + PDT
CPN probes

Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy

Bioimaging

Conclusions

PTB7-based probes as bioimaging agents *in vitro*



A549 cell line

Incubated with CPNs overnight



Washed, fixed and then imaged

400-640 nm excitation (filtered microscope lamp)

700-1000 nm collection window



Superimposed BF and PL images



Introduction

Theranostics

PL + PDT

CPN probes

Results

Fabrication

Size of CPNs

ABS and PL

PDT efficacy



Bioimaging

Conclusions

Conclusions

PTB7 CPN-based theranostic probes

- NIR-active – minimizes tissue absorption
- Appropriate size
- Stable *ex vivo*, *in vivo* and under physiological conditions
- Low dark cytotoxicity
- Produce ROS under photo-excitation
- Can be functionalized to endue specificity to tumours
- Probe properties depend on *stabilizing shell*!
- **F127-stabilized PTB7 CPNs particularly promising**



Current / future work

- Adding targeting capability to PTB7@F127 CPN (Miao, *in preparation*)
- Optically separating the imaging and photosensitizing modalities (Anton)

Introduction

Theranostics

PL + PDT

CPN probes

Results

Fabrication

Size of CPNs

ABS and PL

PDT efficacy

Bioimaging

Conclusions

Acknowledgements

People:

King's College London


Edward Leggett
Dr. Struan Bourke
Dr. Sadie Carter-Searjeant
Dr. Steve Po
Dr. Marciano Palma do Carmo
Prof. Mark Green

University of Hertfordshire

Souzana Poursanidou
Dr. Laura Urbano
Prof. Sean G. Ryan



Dr. Miao Zhao



Anton Uzunoff


Newcastle University

Prof. Philip Manning
Prof. Deborah Tweddle

Other

Prof. Lea Ann Dailey – University of Vienna
Mr Hany Gabra – Paediatric Surgeon, RVI
Dr. Dave Simpson – CEO, Iksuda Therapeutics
Dr. Andrew Chaloner – CEO, Stream Bio

**Thank you for your
attention!**



Funding:



Introduction

Theranostics
PL + PDT
CPN probes

Results

Fabrication
Size of CPNs
ABS and PL
PDT efficacy
Bioimaging

Conclusions